



Disassembling Compaq Mini 110 Keyboard

Remove the keyboard.

Written By: alea



INTRODUCTION

Sticky keys? Simply just want to get rid of your keyboard? Here's how.

TOOLS:

- [Spudger](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery




- Find the battery and the battery tabs located on the bottom of the Compaq Mini.

Step 2




- Push the tabs inward and slide the battery out.

Step 3 — RAM



- Find and remove the two screws on the bottom of your Compaq Mini covering the memory compartment.
- ⓘ Note that the screws are attached to the panel.

Step 4



- Push out side tabs.


Step 5 — Keyboard



- Remove the rubber pads located on the corners of your Compaq Mini.

⚠ There may be junk underneath it. This is residue left from the glue that held on the rubber pad. Just scrape it away to find the screw.

Step 6



- Unscrew all the corner screws. There are four total, one under each rubber pad.

Step 7



- Unscrew the screw for the bottom case located in the RAM compartment.

Step 8



- Remove the three screws in the silver tabs at the back of the keyboard. The red circles show where they are located at the back of the base under the screen.

To reassemble your device, follow these instructions in reverse order.

